



AVA EDGE VENT INSTALLATION GUIDE

www.avaedge.com



Step 1: Remove current Vent
Lift and remove the current vent cover from the floor opening.



Step 4: Smooth the Edges
File or sand the edges to ensure a clean and smooth fit for the new vent cover.



Step 2: Test Fit New Frame
Place the AVA Edge templet over the opening to check alignment and fit.



Step 5: Clean the Area
Vacuum thoroughly around the duct to remove any dust and debris.



Step 3: Trim for Fit
Using a multi-tool or router, depending on the template design, carefully trim the surrounding flooring inside the template opening as needed to ensure the AVA Edge vent fits properly.



Step 8: Final Appearance
Confirm the vent is perfectly flush and aligned for a seamless, modern look.