

AVA EDGE VENT INSTALLATION

www.avaedge.com



Step 1: Remove current Vent
Lift and remove the current vent cover from the floor opening.



Step 5: Clean the Area
Vacuum thoroughly around the duct to remove any dust and debris.



Step 2: Test Fit New Frame
Place the AVA Edge frame over the opening to check alignment and fit.



Step 6: Insert Support Plate
Place the interior support plate into the duct opening by sliding it in between the subfloor and floor.



Step 3: Trim for Fit
Using a multi-tool, cut the surrounding floor if necessary to fit the AVA Edge frame properly.



Step 7: Position the Vent
Make sure support plate is in place.



Step 4: Smooth the Edges
File or sand the edges to ensure a clean and smooth fit for the new vent cover.



Step 8: Final Appearance
Confirm the vent is perfectly flush and aligned for a seamless, modern look.